

# Work Order ID 75756

**\*75756\***

Page 1

October-28-11 11:55:55 AM

Item ID: D206-642-113 Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: Stop **\*NS2\***  
 Item Name: Skidtube LH  
 Start Date: 28/10/2011 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 15/12/2011 Req'd Qty: 1.00 **\*1\*** Customer:  
 Reference:

Approvals: Process Plan: M.L.J Date: 11/10/28 Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start **\*NR1\***  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
<b>Draw Nbr</b>	<b>Revision Nbr</b>								
IIN-D206-642	O								
100	DOCUMENT CONTROL	0.00							<u>M.L.J 11/11/15</u>
<b>*100*</b>									
DC	Memo	0.00							
Document Control	Photocopy bluefile & type labels per PPP206-642-113-CHG001								<u>CHG001 5/12/01/13</u>
	K10111 CHG002								
110	Pick Kit	0.00							
<b>*110*</b>									
Packaging	Memo	0.00							<u>Perf 01/13</u>
Packaging									
120	QC4- 100% Inspect kits for completeness	0.00							
<b>*120*</b>									
QC	Memo	0.00							<u>5/12/01/13</u>
Quality Control									

**B76599LH**

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

**Work Order ID 75756**

October-28-11 11:55:55 AM

**\*75756\***

Page 2

Item ID: D206-642-113

Accept

**\*N900040100\***Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Skidtube LH

Start Date: 28/10/2011 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 15/12/2011 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_  
QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Run Start **\*NR1\***Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

130

0.00

**\*130\***

Packaging

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPPD206-642-113

K10111

Location: ARPPP Rev: ASP 12-01-13

140

QC21- Final Inspection - Work Order Release

0.00

**\*140\***

QC

Memo

0.00

Quality Control

12/1/13MF  
12-01-13

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

October-28-11 11:56:02 AM

Page 1

Work Order ID: 75756

**\*75756\***

Parent Item: D206-642-113

**\*D206-642-113\***

Parent Item Name: Skidtube LH

Start Date: 28/10/2011

Required Date: 15/12/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV:N DD VERF:EC  
REV:B 11.09.23 ADDED K10111 DD VERF:EC

IPP

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D206-642-151		Manufactured	No			110	Each	0.0000	1	1			
<b>*D206-642-151*</b>									<b>**</b>				
Replacement Skidtube													
K10111 <i>CH1013</i>		Manufactured	No			110	Each	0.0000	1	1			
<b>*K10111*</b>									<b>**</b>				
Saddle, Skidtube 206													

*76599*

*B75864 SP.*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries